



SESSION



Massage Wand
Instruction Manual

Product Specifications

Material

Skin-Friendly Liquid Silicone

Size

203 x 51 x 47 mm

Waterproof

IPX7 Waterproof

Noise

≥50db

Charging Duration

2 - 2.5 Hours

Battery Life

Up 2 Hours Depending on Power Setting


Charging

USB Charging

Content


Instructions for Use	5-8
Battery / Charging	9
Maintenance	10
Lubricant	10
Attention	11
Contacts	12


Massage Wand



Instruction for use

01


Press and hold  for 1.5 seconds, the power button will illuminate and enter the vibration mode, there are 12 vibration modes that can be adjusted by tapping the power button.



Instruction for use

02


In the power-on state, short press the "+" key to increase the intensity, short press the "-" key to reduce the intensity, 5 levels of intensities can be adjusted.



Instruction for use


03


In the power-on state, long press the "+" key to jump to the strongest intensity level.



Instruction for use

04

Press and hold  for 1.5 seconds, to shut down, and the light will go off.




Battery / Charging

01

Fully charge before first use. If left idle for an extended period, fully charge before using.

02

When the battery is lower than 20%, a red light behind the power button will turn on to warn that the battery is low.



03

When charging, the power button will illuminate in red. The power button will illuminate in white when charging is complete.



04

Do not use while charging.

Maintenance

01

This toy is waterproof. Always clean after each use, using either soap and water or a water-based sex toy cleaner. Do not use 100% alcohol-based solutions. Dry thoroughly.

02

Store separately from other toys, and away from extreme heat or cold.

Lubricant



Safe to use with any water-based product. Do not use with silicone-based lubricants.

Attention

01

This device is powered by a rechargeable lithium-ion battery. Its expected lifespan is dependent on frequency of use. The product is backed by a two-year limited warranty. Sign up here: sessionplay.com/pages/warranty.

02

When using this product, if you find the product is damaged or have any discomfort, please stop using it immediately.



At Session, your pleasure is our business. It's important to us that you're satisfied with our products. If you have any questions, please feel free to contact us 24/7.

Online feedback helps companies like ours grow – which means more future products, more varieties, and more of everything you love about Session. If you're happy with your order, please leave us a review. And if you're not - don't hesitate to get in touch so we can make it right!

Questions?

Email us 24/7 at
support@sessionplay.com